



สีซูเปอร์ค็อก สีทาฝ้าเพดาน เป็นสีน้ำอะครีลิก ชนิดฟิล์มสีด้านเป็นพิเศษ ผลิตจากอะครีลิกคุณภาพสูงเพื่อการตกแต่งฝ้าเพดาน โดยเฉพาะ ยึดเกาะกับพื้นผิว และให้การปกปิดดีเยี่ยม ช่วยอำพรางความบกพร่องจากงานปูน อาทิเช่น รอยต่อของฝ้าเพดานที่ฉาบไม่เรียบ อีกทั้งยังช่วยลดการสะท้อนของแสงบนฝ้าเพดาน ไม่ผสมสารตะกั่วและปรอท เหมาะสำหรับทาฝ้าเพดาน และฝ้าฝ้ายิปซัมทุกชนิด

## ข้อมูลทางเทคนิคและคุณสมบัติของฟิล์มสี

ประเภทสี	สีน้ำอะครีลิก
ลักษณะฟิล์มสี	ด้าน
ขนาดบรรจุ	1 และ 15 ลิตร
เฉดสี	โปรดดูจากแคตตาล็อกสีซูเปอร์ค็อก
เนื้อสีโดยปริมาตร	35 - 40%
ระยะเวลาแห้งสัมผัส	ไม่น้อยกว่า 30 นาที
ระยะเวลาทาทับ	30 นาที - 2 ชั่วโมง
ระยะเวลาแห้งสมบูรณ์	อย่างน้อย 7 วัน
การครอบคลุมพื้นที่ตามทฤษฎี	35 - 40 ตร.ม. / เทียว / แกลลอน
*พื้นที่ครอบคลุมเป็นค่าทางทฤษฎี อาจแตกต่างจากการใช้งานจริงไม่เกิน 20%	

## วิธีการใช้งาน

วิธีการใช้งาน	แปรง ลูกกลิ้ง หรือสเปรย์
การผสมก่อนใช้งาน	ใช้ได้ทันที หรือหากต้องการผสม ให้เติมน้ำสะอาด 1 ส่วนต่อสี 10 ส่วน (10%)
การทำความสะอาด	ล้างทำความสะอาดอุปกรณ์ด้วยน้ำเปล่าทันทีหลังการใช้งาน

## ระบบการทาสี

ก่อนการทาสีทุกครั้ง พื้นผิวจะต้องแห้ง สะอาด ปราศจากฝุ่นละออง เศษซีเมนต์ คราบไขมัน และสิ่งสกปรกต่างๆ หากมีรอยแตกร้าวกว้างไม่เกิน 1 มม. ให้ซ่อมด้วยสีโป๊วซูเปอร์ค็อก อะครีลิก (A952-400) แล้วขัดแต่งให้เรียบและให้แน่ใจว่าผนังไม่มีรอยร้วซึมของน้ำ เพื่อป้องกันฟิล์มสีโป่งพองภายหลัง

### ขั้นที่ 1 การเตรียมพื้นผิว

- พื้นผิวปูนใหม่ไม่เคยทาสี หรือทาสีแล้วสียังอยู่ในสภาพดี
- พื้นผิวปูนเก่าที่เสื่อมสภาพ

ทิ้งพื้นผิวปูนแห้งสนิทอย่างน้อย 1 เดือน หลังจากฉาบปูน มีความชื้น ไม่เกิน 14 % ควรขัดล้างสีเดิมที่เสื่อมสภาพออกให้หมด บริเวณที่มีเชื้อรา หรือตะไคร่น้ำ ให้ล้างด้วยน้ำสะอาด ทิ้งให้แห้งแล้วทาดูด้วยน้ำยากำจัดเชื้อราและตะไคร่น้ำ ดูลักซ์ เวเธอร์ชีลด์ ไมลดวอช โดยทาทิ้งไว้ข้ามคืน จากนั้นขัดล้างออกด้วยน้ำให้สะอาด ทิ้งไว้ให้แห้งสนิท การขัด หรือการขูดเนื้อฟิล์มสีด้วยความร้อน อาจทำให้เกิดฝุ่นหรือพุ่มอันตรายน หากทำได้ควรใช้วิธีการขัดด้วยแปรงและน้ำแทน ควรปฏิบัติงานในที่ที่มีอากาศถ่ายเทสะดวกและสวมอุปกรณ์ป้องกันส่วนบุคคลที่เหมาะสม

### ขั้นที่ 2 การทาสีรองพื้น

- พื้นผิวปูนใหม่ไม่เคยทาสี หรือทาสีแล้วสียังอยู่ในสภาพดี
- พื้นผิวปูนเก่าที่เสื่อมสภาพ เป็นฝุ่นขอลกหรือไม้สังเคราะห์ ไฟเบอร์ซีเมนต์หรือพื้นผิวที่มีการใช้วัสดุฉาบเรียบ

ทาสีรองพื้นปูนใหม่กันต่างซูเปอร์ค็อก A917-800 จำนวน 1 เทียว ทิ้งให้แห้งอย่างน้อย 30 นาที - 2 ชั่วโมง ก่อนทาสีทับหน้า ทาน้ำยารองพื้นปูนเก่า ซูเปอร์ค็อก มาฟิกซ์ A538-600 จำนวน 1 เทียว ทิ้งให้แห้งอย่างน้อย 10 - 12 ชั่วโมง ก่อนทาสีทับหน้า

### ขั้นที่ 3 การทาสีทับหน้า

ทาสีทับหน้าด้วยซูเปอร์ค็อก สีทาฝ้าเพดาน อย่างน้อย 2 เทียว โดยทิ้งระยะห่างระหว่างสีที่ทาชั้นแรกและชั้นถัดไป ประมาณ 30 นาที - 2 ชั่วโมง



CM-A2N-V-2016.1.13.70



ISO 9001 QMS03026/630  
ISO 14001 EMS05021/198  
OHSAS 18001 OHSAS04016/079  
TIS 18001 OHS01013/028



# Supercote Ceiling Paint

## Acrylic Emulsion for Ceiling



**Supercote Ceiling Paint**, Acrylic premium emulsion paint with super matt finish form high quality resin specially for ceiling area. Good adhesion with high opacity providing smooth finish, borderless of ceiling and light reflection reduction. Contains no added lead and no added mercury. Suitable for decoration of concrete, cement, and gypsum board.

### Technical Information & Paint Film Properties

Type of Paint	Acrylic emulsion
Finish	Matt
Pack size	1 and 15 Liters
Colour Offer	Please refer Supercote Emulsion colour card
Volume Solids	35 - 40%
Touch Dry	At least 30 minutes
Recoat Dry	30 minutes - 2 hours
Full Cure	At least 7 days
Theoretical Coverage	35 - 40 Sq.m./Coat/U.S.Gallon

\*Coverage is theoretical value and may differ from real application +-20%

### Application

Application Method	Brush, Roller or Spray
Mixing Ratio	Ready to use. Can be thinned with 1 part of clean water to 10 parts of the product (10%)
Cleaning Up	Clean all equipment with clean water immediately after used

### Application System

Before painting every time, the surface must be cleaned until free from dirt and grease. If any, repair small cracks smaller than 1mm Supercote Wall Putty. Rub down and make sure no cracks appeared for any possible water leakage in order to prevent paint film blistering later on.

#### Step 1: Surface Preparation

- *New masonry or previously painted in good condition* Leave new masonry to be fully cured at least 1 month. Moisture not over 14%. Allow surfaces to dry out.
- *Previously painted or powdery surfaces* Rub down and treat any area affected by fungus and algae with Dulux Weathershield Mouldwash and leave it overnight. Then rinse off with water and allow the wall to dry.  
Treatments such as sanding, burning off etc of paint films may generate hazardous dust and/or fumes. Wet sanding/flattening should be used wherever possible. Work in well ventilated areas. Use suitable personal protection equipment.

#### Step 2: Priming

- *New masonry or previously painted in good condition* Apply 1 coat of Supercote Acrylic Alkali Resisting Primer A917-800. Allow at least 30 minutes - 2 hours to dry before applying topcoat.
- *Previously painted, powdery surfaces, fiber-cement or skim coat surfaces:* Apply 1 coat of Supercote Mafix Renovating Primer A538-600 and allow 10 - 12 hours drying prior applying topcoat.

#### Step 3: Topcoat

Apply at least 2 coats of Supercote Ceiling paint. Allow at least 30 minutes - 2 hours drying between coats.



CM.AZN-V-2016.1.13.70



ISO 9001 QMS03026/630  
ISO 14001 EMS05021/198  
OHSAS 18001 OHSAS04016/079  
TIS 18001 OHS01013/028

The information in this datasheet is given to the best of our knowledge based on laboratory testing and for use recommendation. As the product is often used under conditions beyond our control, the company cannot guarantee anything only the quality of the product.

AkzoNobel Paints (Thailand) Ltd. (Former ICI Points (Thailand) Ltd.) 34/5 Moo 1 Choeng Watana Road, Klongklue, Pakkred Nonthaburi 11120  
Customer Service : Telephone (662) 572-8888 Fax (662) 572-8889, www.dulux.co.th, www.facebook.com/duluxthailand